

## Notice: Bypass Breakers and Battery DC Disconnect

**Condition:** If an error occurs in the Adara Energy Storage System and if the grid is still available and powering non-protected loads, the homeowner can bypass the Adara system by moving the Bypass Interlock switch located in the Breaker and Bypass Box down to the Bypass position. The protected loads will then be powered from the grid and Adara Support ([support@adarapower.com](mailto:support@adarapower.com)) should be contacted to initiate a remote diagnostic test on the system.

